
Machine Status & Production

N PA	licrosoft Excel - IMPAX T	SS Viewer.xls						_ 8 ×					
	Eile Edit View Insert Format Tools Data Window Help Acrobat IMPAX TSS Functions Type a question for help 🔹 🗗 🗙												
	A1 - 5												
	A B	C	D E F		H I J K		M N	0 F_▲					
		IMP		wing System	Intro	Summary	OEE View						
1			Detail View	Reporting	Setup								
2	Summary View Detail View Reporting Setup												
3		Shop Floor Summary Print this Page											
4	Machine		Current	Status	Daily S	tatus							
6	Machine	Machine	Current	Ideal	Today's	Today's View C	1000	lachine					
7	Name	Status	PPM	PPM	Performance	OEE Deta	ils Deta	uils					
9	Header 1	Up: 22:49	95	100	89.1%	89.1%	View De	tails					
11	Header 2	Up: 3:19	97	100	75.5%	71.7%	View De	tails					
13	Header 3	Down: 3:45	0	100	62.1%	42.8%	View De	tails					
15	Header 4	Up: 6:40	102	100	79.4%	59.6%	View De	tails					
17	Header 5	Up: 1d 2:53	82	100	96.7%	96.7%	View De	tails					
19	Roller 1	Up: 7:24	54	100	82.5%	72.6%	View De	tails					
21	Roller 2	Down: 0:15	0	100	87.4%	85.7%	View De	tails					
23	Roller 3	Down: 12:55	0	100	22.6%	9.0%	View De	tails					
25	Roller 4	Up: 9:27	87	100	68.3%	51.2%	View De	tails					
27	Roller 5	Up: 21:40	90	100	71.5%	57.2%	View De	tails					
29													
31													
33													
35													
37													
	► ► Intro Summary	View (OEE View (Deta	il View 🖊 Reporting	/ Downtime Repo	rt 🖌 Times Report 🖌 Setup /	•							
Read	ły							NUM					


		Tool Us	age Cou	ints & Ma	aintena	nce Tas	k Count	ts		
	icrosoft Excel - IMPAX TSS Viewer.xls									
	<u>File Edit View Insert Format T</u> ools			IMPAX TSS F					Type a question	on for help 🚽 🗖 🗙
	🛩 🖬 🔁 🎒 🕼 🖤 👗 🖻 🛍 •	🖋 Ka + Ka + 🤮	$\Sigma = \frac{A}{2}$	Z 🗍 🛍 🚜	100% -	2.				
	A1 ▼ fx									
	A B C D	E F	G	H		J	K	L	<u>M N</u>	0 P -
	l IM	PAX	TSS	Viewi	ng S	ysten	n _	Intro	Summary	OEE View
1				Detai	l View			Detail Viev	w Reporting	Setup
2	-	Detail View f	or mac	hine: I	Heade	r 1		-	Print this Pag	je
4										
41										
42	Tool Counters	(chan	ge color t	o yellow at	75	percent	t, and to i	red at 100	percent)	
43 44						TOOL 6		TOOL 8 TO		
44	Expected Life:	RILL CHISEL 700000 22000000	PUNCH 5500000		0015	1001.0	001		00L 9	
45	Life Used:	559558 1013488		<u> </u>	0	0	0		0	
40	Life Remaining:	140442 20986512			0	0	0		0	
48		2000012	1100010	¶ ∛	•	v		, v		
49						_				
50	Maintenance Coun	ters (chan	ge color t	to yellow at	75	 percent 	t, and to i	red at 100	percent)	
51	-									
52	F	DIL LUBE	FILTER		MAINT. 5	MAINT. 6		MAINT. 8 M	IAINT. 9	
53	· · ·	7777777 6000000		0	0	0	0		0	
54	E	1186285 1186271	1186257	0	0	0	0		0	
55 56	Life Remaining:	6591492 4813729	1313743	0	0	0	0	0	0	
57										
58	Downtime Reason	IS	Show C	odes: 1	- 16 -	(Tim	es are hh:r	mm)		
59					Codes			Yearly C	odes	
60	Code Description	Occur.	Time	Occur.	Time	Occur.	Time	-	Times	
61	1 MACHINE SETUP	1	0:45	5	6:53	13	12:14	20	20:20	
62	2 MAINTENANCE	2	0:22	10	3:05	18	5:42	26	8:35	_
	► N Intro / Summary View / OEE View)	Detail View / Report	ng / Down	time Report /	Times Repo	ort / Setup /	/ ^ ^ ^		0.00	
Read										NUM

Uptime and Downtime Minutes and Percentage Microsoft Excel - IMPAX TSS Viewer.xls _ 8 × - - 8 × 🖳 🔚 🖪 Edit View Insert Format Tools Data Window Help Acrobat IMPAX TSS Functions Type a question for help A D V X B A · V ∽ · · · 🍓 \Sigma - 🍂 🕌 🕍 🚛 👫 100% - 🕐 _ 📙 🎨 I 🗅 📂 A1 fx А B С D F F G K Μ Ν 0 P н **TSS Viewing System** Summary Intro **OEE View Detail View Detail View** Reporting Setup 1 2 Print this Page Detail View for machine: Header 1 3 4 23 **Up/Down Times** 24 (Times are hh:mm) 25 **Daily Minutes** Weekly Minutes Monthly Minutes Yearly Minutes 26 Up Down Resp. Down Resp. Up Down Resp. Up Down Resp. 27 Up Shift 1: 1d 18:32 28 0:21 0:06 0:52 0:23 8:32 7:02 0:06 7:02 0:21 11 days 3:21 Shift 2: 29 0:00 0:00 0:00 0:00 0:00 0:00 1d 15:35 0:48 0:15 11 days 14:02 6:35 Shift 3: 30 0:00 0:31 3:06 0:00 0:00 0:00 0:00 0:00 1d 20:51 1:04 9d 21:33 5:51 31 Total: 0:06 1:09 7:02 0:21 0:06 7:02 0:21 5d 6:58 2:44 32 days 1d 4:25 13:02 32 33 Production Counts Daily Weekly Monthly 34 Yearly 35 Count Scrap Count Count Count Order Counters: Shift 1: 36 41000 0 41000 246851 1485245 Order Quantity: Shift 2: Minutes Left: 1478523 37 10000 77 0 0 0 248742 Parts Made: Parts To Go: Shift 3: 38 7535 0 0 2465 0 232315 1418740 Percent Made: Percent To Go: 0 41000 727908 Total: 41000 4382508 39 24 76 40 41 **Tool Counters** (change color to yellow at 75 repercent, and to red at 100 repercent) 42 43 44 DRILL CHISEL PUNCH TOOL 4 TOOL 5 TOOL 6 TOOL 7 TOOL 8 TOOL 9 0 0 0 700000 22000000 5500000 0 0 45 Expected Life: 0 H → ▶ H Intro / Summary View / OEE View / Detail View / Reporting / Downtime Report / Times Report / Setup / F NUM Ready



Downtime Reason Breakdown

Uptime vs. Downtime Analysis



Downtime Occurrences & Response Times

🔀 M	icrosoft Excel - IMPAX TSS Viewer.xls										_	. 8 ×
8	📳 File Edit View Insert Format Tools Data Window Help Acrobat IMPAX TSS Functions Type a question for help 🗸 🗗 🗙											
	A B C D E	F	G	Н		J	K	L	М	N	0	P 🔺
		🗾 TSS Viewing System						inuo		ummary	OEE VIEV	~
1				Deta	il View		Detail View F		porting	Setup		
2	-											_
3	Detail	View f	or mad	hine:	Heade	r 1		-	Prin	t this Pag	e	
4	D otain		or mac		mouuo	••						
57						_						
58	Downtime Reasons		Show C	odes:	1 - 16 🝷	(Tim	nes are hh:	mm)				
59		Daily	Codes	Weekly	/ Codes	Monthl	y Codes	Yearly	Codes			
60	Code Description	Occur.	Time	Occur.	Time	Occur.	Time	Occur.	Times	_		
61	1 MACHINE SETUP	1	0:45	5	6:53	13	12:14	20	20:20			
62	2 MAINTENANCE	2	0:22	10	3:05	18	5:42	26	8:35			
63	3 PART CHANGE	0	0:00	0	0:00	0	0:00	0	0:00			
64	4 ORDER COMPLETE	0	0:00	0	0:00	0	0:00	0	0:00			
65	5 SMASHUP	0	0:00	0	0:00	1	7:53	1	7:53			
66	6 BREAKDOWN	2	1:30	8	3:17	8	3:17	12	5:32			
67	7 TOOL ADJUST	0	0:00	4	0:41	9	1:31	9	1:31			
68	8 TOOL CHANGE	0	0:00	0	0:00	2	0:13	2	0:13			
69	9 SAMPLES	0	0:00	0	0:00	4	0:43	4	0:43			
70	10 FEED PROBLEMS 11 MATERIAL QUALITY	0	0:00	0	0:00	1	0:15	1	0:15			
71	12 WAITING FOR MATERIAL	0	0:00	0	0:00	5 2	1:45 0:11	5 2	1:45 0:11			
72	13 MEETING/TRAINING	0	0:00	0	0:00	0	0:00	0	0:00			
74	14 WAITING FOR OPERATOR		0:00	0	0:00	1	0:25	1	0:25			
75	15 WORKING ON OTHER MA		0:00	0	0:00	0	0:00	0	0:00			
76	16 SCHEDULED SHUTDOW		0:00	0	0:00	0	0:00	0	0:00			
77												
78	Downtime Occurrences		Show O	ccurrend	ces: 1	-8 -						
79	Start Start	End	Resp.		Downtim		Downtim	е				-
	► ► ► Intro / Summary View / OEE View Detail View								•			
Read	y										NUM	

Overall Equipment Effectiveness (OEE)

- 1 - 1

N	licrosoft Excel	- IMPAX TSS V	/iewer.xls									_ 8	
	Eile Edit View Insert Format Tools Data Window Help Acrobat IMPAX TSS Functions Type a question for help 🗸 🗗 🗙												
	A1 $rac{f_x}{r}$ A B C D E F G H I J K L A												
		Intro Summary										OEE View	
1		OEE View Detail View Reporting										Setup	
2													
3		Overall Equipment Effectiveness (OEE) Summary											
4	-		в	с		-	F	c				Tedeule	
5	Machine	A Today's	в Today's		D Availability	E Today's	F Expected	G Performance	H Today's	Today's	J Quality	Today's OEE	
7	Name	Elapsed	Downtime	-	Percent	Parts	Parts	Percent	Parts	Scrap	Percent	Percent	
8		Time			(C / A)		(based on PPM)		Made	Parts	((H - I) / H)		
11	Header 1	12:32	0:00	12:32	100.0%	67003	75200	89.1%	67003.2	C	100.0%	89.1%	
13	Header 2	12:32	0:37	11:54	95.0%	56776	75200	75.5%	56776	C	100.0%	71.7%	
15	Header 3	12:32	3:53	8:38	69.0%	46699	75200	62.1%	46699.2	C	100.0%	42.8%	
17	Header 4	12:32	3:08	9:24	75.0%	59709	75200	79.4%	59708.8	C	100.0%	59.6%	
19	Header 5	12:32	0:00	12:32	100.0%	72718	75200	96.7%	72718.4	C	100.0%	96.7%	
21	Roller 1	12:32	1:30	11:01	88.0%	62040	75200	82.5%	62040	C	100.0%	72.6%	
23	Roller 2	12:32	0:15	12:16	98.0%	65725	75200	87.4%	65724.8	C	100.0%	85.7%	
25	Roller 3	12:32	7:31	5:00	40.0%	16995	75200	22.6%	16995.2	C	100.0%	9.0%	
27	Roller 4	12:32	3:08	9:24	75.0%	51362	75200	68.3%	51361.6	C	100.0%	51.2%	
29	Roller 5	12:32	2:30	10:01	80.0%	53768	75200	71.5%	53768	C	100.0%	57.2%	
31													
33													
35													
37													
39													
I •	I ▶ ▶I \ Intro ,	Summary View	∕ ∖OEE View ∕	Detail View	/ Reporting / D	owntime Rep	oort 🔏 Times Repor	t / Setup /	[•		 ►	
Rea	dy											NUM	